



Figure 1. Cross-section of flow past approach embankment abutment, showing Boundary Layer Wedge (BLW)